

Application Note

4/15/2020



Installing a DISH Mexico system using the XR-3 Satellite Meter



Connections: Coax cable connected from an output port of LNBF to XR-3 satellite meter module's ODU / LNB port

Note: the below setup assumes that you have the Carib-CentralAm Field Guide and No Postal Code databases loaded. If you have the North American Field Guide loaded, use the FlashUpdate program to download the appropriate software.

Meter set-up

Press the **SYST** System soft-key (located near top left corner of LCD screen) to enter the System Setup menu. Then select the following:

- REGION **Mexico**
- SERVICE **Dish Mexico (Mexico)**
- SYSTEM **77.0 QuetzSat 1**
- LNB MODEL **Legacy Single** or **DP Single**, depending on your hardware (most likely DP Single)
- SWITCH TYPE defaults to **none** (assuming you'll be connected directly from ODU/LNB port of meter module to LNBF output port)

*To make selections, arrow up or down to the item to change and press **Enter**, then arrow up or down to the desired option and press **Enter**. Press **EXIT** or **DONE** to return to Run Mode*

Azimuth/Elevation Lookup:

Press the **AZ/EL** soft-key (lower left corner of main run screen), use the numeric keypad to enter the latitude and longitude coordinates (in digital degrees) of your current location, and press the **ENTER** key. Press **EXIT** to return to Run Mode.

Antenna Pointing

Install the mast (pole) plumb, preset the antenna reflector's vertical angle (elevation setting) and Skew setting, mount antenna reflector to mast, and grossly align azimuth (using magnetic compass according to 'Magnetic' compass coordinates shown in AZ/EL screen on meter). You may want to use the AZ/EL look-up feature to obtain rough antenna reflector settings based on your latitude and longitude.

Application Note

4/15/2020



Run Mode:

- Press **LNB** soft-key (located on middle right side of LCD screen) once to power the LNB. The satellite orbital position will be shown in upper left corner of LCD screen. (77°W)
- Adjust antenna reflector azimuth (left or right) and elevation (up or down) to obtain maximum signal level (left bar graph), signal quality (right bar graph), and LOCK status.
- Press the **ID** soft-key (located on middle left side of LCD screen) to verify that you're aligned to the correct satellite. "ID VERIFIED" means you are pointed correctly.
- If "ID FAILED" is displayed, press **SCAN** soft-key and the XR-3 will find which satellite you are aimed at.
- If desired, you may also use Up/Down arrow keys to scroll through other transponders to check for proper level and quality.

Limit Scan (Optional Step for PASS/FAIL grading of installations)

- Press the **MENU** soft key.
- Press the **LIMIT SCAN** soft key or scroll and highlight **Limit Scan** and press **Enter**.
- Press the **EDIT LIMITS** soft key and enter the desired transponder numbers, minimum signal quality, average signal quality, RF level, and frequency deviation limits. Then press **EXIT**.
- Press **Scan All** to perform limit scan.
- Review results or save them in meter for future use.

You may also choose to use the PoP Scan function of the meter to record the measurements. Please refer to the operations manual for more information and instructions related to the Proof of Performance scan feature.

Notes:

- It is NOT recommended to keep the XR-3 meter in line while checking receiver status due to attenuation from our circuitry.
- Please ensure that you have the latest versions of Carib-CentralAm Field Guide and Software loaded into your meter. If your meter has older versions loaded, please use the FlashUpdate program to update your meter, as described in the Operations Manual.



TesCom • 20200 Algreg St • Pflugerville, TX 78660 • Tel (512) 244-6689
www.appliedin.com & www.tescomusa.com