



## Application Note

10/16/2012

### Installing a DIRECTV SL3 KaKu system with the Super Buddy™ satellite meter

**Connections:** Coax cable connected from an output port of DIRECTV SL3 LNBF to top (SIGNAL IN) port of Super Buddy meter.

#### Meter set-up

Press the **SYST** System soft-key (located near top left corner of LCD screen) to enter the System Setup menu. Then select the following:

- REGION your geographic region
- SERVICE **DIRECTV**
- SYSTEM **SL3 LNB**
- LNB MODEL defaults to **SL3 LNB** (but user may change to other menu options for LNB model if going through a 6x8 multi-switch and/or if using a wing dish aimed at the 95 satellite)
- SWITCH TYPE defaults to **22 kHz** (or may default to DTV6x8 if user has indicated that he is passing signal through 6x8 multi-switch before entering meter)

*To make selections, arrow up or down to the item to change and press **Enter**, then arrow up or down to the desired option and press **Enter**. Press **EXIT** or **DONE** to return to Run Mode*

#### Antenna Pointing

Install the mast plumb, preset the antenna vertical angle, mount to mast, and grossly align azimuth. You may want to use the ZIP zip code look-up feature to obtain rough antenna settings (magnetic compass heading, elevation, and tilt/skew).

After completing the System Setup:

- 1) Press DONE or EXIT to return to the main Run screen.
- 2) Adjust the tilt / skew of the dish (rotating dish about a point) based on the parameters provided by the Super Buddy's zip code lookup feature (ZIP soft-key in lower left corner of main Run screen).
- 3) Connect a coax jumper cable from the top (Signal-In) port of your Super Buddy meter to a LNBF output port.

#### **Rough Alignment of Azimuth and Elevation of dish on 101°W Satellite**

##### **To find the 101° satellite:**

- Press the LNB soft-key (located on middle right side of LCD screen) to apply power to the LNB. LNB1 is for the 101° satellite.
- Adjust the azimuth and elevation of the dish to optimize the alignment by maximizing the signal level (left bar graph) and signal quality (right bar graph) on the 101 satellite. Align antenna until a LOCK status is obtained.
- After you see LOCK, press ID soft-key (located on middle left side of LCD screen) and verify that the 101 satellite has been found.

### ***Dithering (Fine-Tuning) of Azimuth/Elevation of dish on 101°W Satellite***

Complete the dithering/fine tuning process to ensure that you're aimed at the center of the beam, adjusting the azimuth and elevation of the dish using the fine adjustment screws while looking at the 101 satellite, as directed by DIRECTV. This should ensure good signal reception from all three satellites (99, 101,103) if your mast/pole is plumb.

Dithering (Fine-Tuning) steps:

- 1) Use the LNB power soft-key to ensure you're tuned to LNB1 (the 101 satellite).
- 2) Using the Azimuth fine-tuning screw bolt, turn clockwise and counter-clockwise until you get the highest signal level (meter's left bar graph) and signal quality (right bar graph) on the 101 satellite.
- 3) Using the Elevation fine-tuning screw bolt, turn clockwise and counter-clockwise until you get the highest signal level (meter's left bar graph) and signal quality (right bar graph) on the 101 satellite.
- 4) Record the signal level (i.e. with pen and paper) that is displayed on meter's left bar graph for 101 satellite,
- 5) Set the Elevation plastic dial to zero.
- 6) Using the Elevation screw bolt, turn 4 full turns counter-clockwise, record the signal level (displayed on meter's left bar graph).
- 7) Rotate the bolt clockwise counting the number of turns until the same signal level is reached.
- 8) Divide this number of turns by 2.
- 9) Turn the Elevation plastic dial to zero.
- 10) Rotate the Elevation screw counter-clockwise by the divided number of turns
- 11) Tighten the Elevation bolts down. The signal level should be the same or higher than with your rough alignment.
- 12) Record the signal level (i.e. with pen and paper) for 101,
- 13) Set the Azimuth plastic dial to zero.
- 14) Using the Azimuth screw bolt, turn 4 full turns counter-clockwise, record the signal level.
- 15) Rotate the fine-tuning bolt clockwise counting the number of turns until the same signal level is reached.
- 16) Divide this number of turns by 2.
- 17) Turn the Azimuth plastic dial to zero.
- 18) Rotate the Azimuth screw counter-clockwise by the divided number of turns,
- 19) Tighten the Azimuth bolts down. The signal level should be the same or higher than with your rough alignment.

DIRECTV has strictly stated that they do NOT want the technicians modifying the alignment of the dish while looking only at the Ka signal level (dBm) because if they improve signal reception from the 103 satellite, they will likely be hurting the alignment on the 99 satellite at the same time. DIRECTV recommends roughly adjusting the azimuth and elevation of the dish while looking at the 101 satellite, and then performing their fine-tuning/dithering process while looking at the 101 satellite. Please refer to DIRECTV's official instructions regarding their dithering/fine-tuning process for more information.

The Super Buddy satellite meter cannot identify and get a LOCK on the DIRECTV 99 & 103 Ka satellites. The Super Buddy can only display signal level (dBm) on your left bar graph for the non-SWM DIRECTV 99 & 103 Ka satellites. The right bar graph (signal quality) will be empty and the meter will NOT indicate a lock status since the Super Buddy meter isn't able to demodulate or obtain a lock on the DIRECTV Ka signals due to the DVB-S2 modulation type and level of encryption. The DIRECTV IRD/satellite receiver can show you the signal quality of the 99 & 103 Ka satellites signals because the receiver is compatible with the signal type and encryption type found on the Ka satellites.

### ***Secure dish and verify adequate signal level and quality:***

- Check all nuts and bolts and make sure they are tightened to specification. Pay close attention to the LNB lock down bolts. They must be installed wrench tight to prevent LNB movement.

Applied Instruments, Inc. • 5230 Elmwood Ave. • Indianapolis, IN USA 46203 • T (317) 782-4331 • [www.appliedin.com](http://www.appliedin.com)

- Check for passing scores (green check marks) on the TV screen that's connected to the powered DIRECTV receiver for the 99, 101, and 103 satellite transponders. If the satellite receiver doesn't pass, then the technician should not leave the site and must improve dish alignment to reach a passing score.

***To check the RF signal level (dBm) of Ka High Transponders on 99° satellite, if desired:***

- Press the LNB soft-key (located on middle right side of LCD screen) to toggle to LNB3 (99° satellite)
- Press your up/down arrow keys to scroll through transponders, as desired
- Pay attention to the signal level (dBm) on your left bar graph. You can ignore the right bar graph (C/N) since the Super Buddy meter isn't able to demodulate or obtain a LOCK on the DIRECTV Ka signal.

***To check the RF signal level (dBm) of Ka High Transponders on 103° satellite, if desired:***

- Press the LNB soft-key (located on middle right side of LCD screen) to toggle to LNB4 (103° satellite)
- Press your up/down arrow keys to scroll through transponders
- Pay attention to the signal level (dBm) on your left bar graph. You can ignore the right bar graph (C/N) since the Super Buddy meter isn't able to demodulate or obtain a LOCK on the DIRECTV Ka signal.